



SDP-ECO1630IIIR PREINSTALLATION CHECKLIST

Installation will not be scheduled until form is returned to Margaret Dellacamera via Fax # (914) 921-0995 or email: margaret@mitsubishiimaging.com

Dealer Name:
Dealer Contact:
Phone Number:
Customer Name:
Installation Address:
Customer Phone Number:
Customer Contact:
Pre-Press Contact:
Pressroom Contact:
Requested Installation Date:
Options
What options have been ordered for the platesetter? None
Trapping Proofing Plug-In Punch
List any other options:





Prepress

ı	P	R	F	P	R	F	5	2	F	R	\cap	۸	ΙП	ΓF	=1	VI.	\Box	١	٨	\cap	١R	k	(5	١;	ΓΔ	٦	ГΙ	\cap	۸	d	9
		ľ			1		. 7				. ,	46	ч і			v		٠,	ıw	١.	,,,	·	١.	7 I	_	١.			,,,	v.	

1. How many of each? If other is selected, p			
2. Is there a file, network or If yes, please list typ			
WINDOWS	MAC UNIX _	DOMAIN	
3. Network Protocol	TCP/IP	Novell IPX	
The RIP computer must ha RIP computer.	ve a static IP addres	ss. Please supp	oly IP information for
IP Address	·		
Subnet mask		<u>. </u>	
Default Gateway			
DNS Server	·		

- 4. Network Cable: The RIP comes with an RJ 45 connector only. If any other connector is needed, contact Margaret at (914) 925-3246.
- 5. There must be a network data connection within 10 feet of the RIP computer. Note: The network cable is not provided. Cat 5E recommended
- 6. There must be a Network Administrator available for networking assistance during installation.





Applications

7. What are yer PageMaker, e	our primary applications used for outputetc.)	t (InDesign, (Quark,				
	1						
	2						
	3						
8. Does custo software.	mer have imposition software, if so, ple		e of imposition				
9. Does customer have trapping software, if so, please list name of trapping software.							
10. Does the	customer have any CTP experience?	YES	 _ NO				
11. Will press	assistance be necessary?	YES	_ NO				
12. Type of pr	ress using plates from the SDP-Eco163	OIIIR.					
WEB_	Sheet fed	Other	<u> </u>				
Please list pre	esses on site and dampener type						
Please list typ	e of fountain solution currently used.						





SDP-Eco1630IIIR Electrical Requirements

110 - 120 VAC 20 amps, 50/60 Hz, dedicated line with isolated ground for platesetter.

RIP Computer Electrical Requirements

100 – 120 VAC 15 amps. 50/60 Hz, dedicated line with SURGE PROTECTOR POWER STRIP for the RIP and related equipment.


ALL ELECTRICAL REQUIREMENTS MUST BE COMPLETED BEFORE INSTALLATION WILL BE STARTED.

Please sign below stating that all requirements will be finished before installation:

Customer Name:		
	(Please Print)	
Title:		
	(Please Print)	
Signature:		



Space Requirements



MACHINE DIMENSIONS

Crated: W 48" x D 36" x H 54" Weight 488 Lbs.

Uncrated: W 39.5" x D 31.3" x H 42.2" Weight 408 Lbs.

Minimum door opening, uncrated: Width 32.0"

Does machine need to be moved through minimum opening? YES ____ NO ____

Is inside delivery necessary? YES NO

Is a lift gate truck necessary? YES____ NO____





- There should be sufficient space around the SDP-Eco1630IIR for installation and maintenance, adding chemistry, re-loading plate material, opening panels, doors, and cleaning.
- A small table for the RIP computer and monitor should be no more than 10 feet from the left side of the platesetter.

Does the customer currently run SDP or SilverMaster? SDP SLM
Has the customer run plate samples prior to installation? YES NO
What are the results of test printing?
_
Chemistry and Plate Material
The SDP-Eco1630IIIR requires SDP-FRS175, SDP-FR100, or SDP-RR175 SPE 725 Plate Material
MINIMUM MATERIAL REQUIRED FOR INSTALLATION
Please list material roll sizes needed for installation.

Operator Training

1 roll each size material used, 1 Cases SLM-EAC2, 1 Case SLM-EST2

Please note: During installation, it is imperative that we have at least one pre-press person, and one press person available for a minimum of two full days of training. If any interruptions cause delays in training, there will be additional charges for training.





Please provide the names of persons in	each area to be trained.						
Pre-press	Press						
Any other additional information that you feel would be helpful for installation, please list below.							